



3009ARF III Windows MCE Remote Control



- 2.4GHz RF technology with an operating range of up to 10m.
- Press the Media Center Start button to access, command, and control your digital entertainment options.
- View more type of entertainment-TV/Video recording, personal Video, Movie, Music, Photos, and Radio as well as control the Media Center.
- Microsoft Windows 7 certification and Green Start Button support to run virtual remote server on your Media Center computer.
- Include all of the buttons and functions necessary for Microsoft certification.
- Conveniently access the PC digital entertainment.
- 5 Teletext menu hotkeys support ISDB data function for the digital television (DTV) and digital radio format.
- Play and Record media directly what you are watching.
- Navigate 4 way to control the cursor arrows.
- Quickly access the Media Center and play the shortcut keys.
- Edit the Digital Photos and Videos directly.
- Shuffle and manage the digital music collection.
- Use metal dome for better tactile feel.
- Mini USB dongle style receiver.

Specifications	
Remote controller	
Key numbers	44 / 49 / 52
Switch activation mechanism	Metal dome
Transmission frequency	2.4GHz
Operation Distance	up to 10m
Dimension	200 (L) x 50 (W) x 27 (H) mm
Weight	100g (not including 2 AAA batteries)
Peak Force	56 +/- 10 g
Receiver	
Connector	USB 2.0
Dimension	51.4 (L) x 17 (W) x 8 (H) mm
Environment Compliant	
	WEEE, RoHS
Agency Approval	
	FCC , CE , BSMI



Layout

■ Standard : 44 buttons



1 Power Button
 Power (Standby)

2 Transport Control Buttons

	Play		Fast Forward
	Pause		Rewind
	Stop		Skip Forward
	Record		Skip Backward

3 Navigation Control Buttons

	Green Start Button (MCE)
	Back
	More
	Cursor Keys
	OK

4 Audio and Video Control Buttons

Vol.	Volume Up
Vol.	Volume Down
	Mute
Ch.	Chan Up
Ch.	Chan Down

5 Media Center Shortcut Buttons

	Recorded TV		Music
	Guide		Pictures
	Live TV		Video
	DVD Menu		Radio

6 Numeric Keypad

	0 - 9
	#
	*
	CLEAR (ESC)
	ENTER

■ Standard with Teletext buttons : 49 buttons



1 Power Button
 Power (Standby)

2 Transport Control Buttons

	Play		Fast Forward
	Pause		Rewind
	Stop		Skip Forward
	Record		Skip Backward

3 Navigation Control Buttons

	Green Start Button (MCE)
	Back
	More
	Cursor Keys
	OK

4 Audio and Video Control Buttons

Vol.	Volume Up
Vol.	Volume Down
	Mute
Ch.	Chan Up
Ch.	Chan Down

5 Media Center Shortcut Buttons

	Recorded TV		Music
	Guide		Pictures
	Live TV		Video
	DVD Menu		Radio

6 Numeric Keypad

	0 - 9
	#
	*
	CLEAR (ESC)
	ENTER

7 Teletext Buttons

	Teletext on/off
	Red
	Green
	Yellow
	Blue



■ **Japanese layout : 52 buttons**



1 Transport Control Buttons

- ▶ Play ⏩ Fast Forward
- ⏸ Pause ⏪ Rewind
- Stop ⏭ Skip Forward
- Record ⏮ Skip Backward

2 Navigation Control Buttons

- 🟢 Green Start Button
- ← Back
- ⓘ More
- ▲ ▼ ◀ ▶ Cursor Keys
- OK OK

3 Audio and Video Control Buttons

- ⏻ Power (Standby)
- Vol. ⏶ Volume Up
- Vol. ⏵ Volume Down
- 🔇 Mute
- Ch. ⏶ Chan/Page Up
- Ch. ⏵ Chan/Page Down

4 Media Center Shortcut Buttons

- 📺 Recorded TV 🎵 Music
- 📖 Guide 🖼️ Pictures
- 📺 Live TV 📺 Video
- 📺 DVD Menu 📻 Radio

5 Numeric Keypad

- 0 - 12
- #
- *
- CLEAR
- ENTER

6 Teletext Buttons

- d Teletext on/off
- Red
- Green
- Yellow
- Blue

System Requirement

- Windows Media Center PC or other peripheral devices with Windows Media Center
- Available USB port

Package Contents

- Remote controller
- Dongle Receiver
- Quick install guide
- 2 x AAA batteries



BTC[®] BEHAVIOR TECH COMPUTER CORP.

<http://www.btc.com.tw>

Headquarters in Taiwan:
TEL: (886)-2-2696-1888
FAX: (886)-2-2696-1899

European Office
France:
TEL: (33)-2-4143-8757
FAX: (33)-1-4670-1897

Netherlands:
TEL: (31)-10-264-2444
FAX: (31)-10-264-2458